

**CALL (888) 406-5318 FOR ALL CUSTOMER SUPPORT NEEDS**  
**Wallpaper removal can be easy! Remember these easy steps:**

**Score!**



**Spray!**



**Scrape!**



**WALLPAPER REMOVAL INSTRUCTIONS:**

- 1.) Peel off top decorative layer, or **SCORE** wallpaper with the WP Chomp Wallpaper Scoring Tool using just enough pressure to perforate paper (excessive pressing of tool against wall will damage drywall and tool). More holes speeds stripper penetration, so score thoroughly.
- 2.) **SPRAY** WP Chomp! World's Best Wallpaper Stripper to perforated wallpaper, applying from the top down. Allow WP Chomp to dwell for 1-5 minutes.
- 3.) **SCRAPE** wallpaper from the wall surface using the WP Chomp Wallpaper Scraping Tool; starting at the top, and working down the wall. Apply gentle forward pressure to the scraping tool (Let the tool do the work - excessive pressure will gouge drywall). To remove remaining wallpaper paste, reapply WP Chomp Wallpaper Stripper, and sponge clean, rinsing with clean water. Allow walls to dry completely before painting.

**Won't damage walls - when used properly**



**CAUTION!**  
 THIS TOOL HAS SHARP POINTS! NOT  
 INTENDED FOR USE BY CHILDREN!



52016

**ENVIRONMENTAL SOLUTIONS INTERNATIONAL, BATAVIA, ILLINOIS**  
**FOR MORE INFORMATION CHECK OUT**  
**[www.healthierhomeproducts.com](http://www.healthierhomeproducts.com)**